

Our Hirose™ quick disconnect adaptors allow users to quickly attach and detach accessories without having to use the connection to the radio.

A great options for users who want to disconnect the radio without removing their accessory, disconnect quickly for charging the radio or quickly change between radios.

Adaptor Options



AD-K1-Hirose - works with Kenwood radios - [View Connector Chart](#)



AD-M12-Hirose - works with Motorola MOTOTRBO radios - [View Connector Chart](#)



AD-M3-Hirose includes PTT and 3.5mm accessory port. [View Connector Chart](#)



- Allows accessory to stay on person while changing or charging radios.
- Adaptor stays connected to the radio and accessories are quickly connected and disconnected to and from the adaptor
- Engineered and designed to ensure quality control

Hirose™ Earpiece Options



AT1W - 1-wire acoustic tube earpiece with straight in-line lapel PTT/Mic



AT+2W - 2-wire Braided Fiber Cloth acoustic tube earpiece with straight in-line PTT / RF-shielded mic



SL+2W - 2-wire SnapLock Braided Fiber Cloth with palm PTT / RF-shielded mic

Earpieces sold separately:

- SL-EB** - Ear Bud
- SL-EH** - Ear Hook
- SL-SWVL** - Swivel
- SL-DR** - D-Ring
- SL-DRA** - Adjustable D-Ring
- SL-AT** - Acoustic Tube
- SL-ATR** - Acoustic Tube Retail